

- 1. THIS CONNECTOR IS NOT REQUIRED IF A TIME CODE READER IS INTERPOSED BETWEEN THE CONTROLLED TRANSPORT AND TAPE SYNCHRONIZER MODULE. IF CONNECTOR IS INSTALLED AND NOT USED, CONNECT PIN 3 TO PIN 1 TO GROUND STC INPUT.
- 2. TO FEED CONTROL TRACK/TACH PULSE AND DIRECTION SIGNALS FROM CONTROLLED TRANSPORT TO TAPE SYNCHRONIZER MODULE, CONNECT P3 TO P4 AS SHOWN. TO FEED CONROL TRACK/TACH PULSE AND DIRECTION SIGNALS FROM CONTROLLED TRANSPORT TO AN INTERPOSED TIME CODE READER MODULE, CONNECT P3 TO TRANSPORT CONNECTOR ON REAR PANEL OF READER MODULE.
- 3. THIS PIGTAIL PROVIDED TO PERMIT INSTALLATION OF AN AUDIO CONNECTOR IF MASTER LTC IS TO BE FED DIRECTLY TO TAPE SYNCHRONIZER MODULE.
- 4. JP4 ON 2600SY MAIN PCB MUST BE ON .3 POSITION.
- 5. TACH IS 64 PPS AT 15 IPS.
- 6. CONSTANT 02 IS 46 AT 15 IPS. CONSTANT 02 IS 56 AT 30 IPS.
- CONSTANT 10 IS 01 AT 15 IPS.
 CONSTANT 10 IS 00 AT 30 IPS.
- 8. 0 VDC INDICATES REVERSE. PUT JUMPER JP6 ON SY PROCESSOR PCB IN RVL POSITION.

-CONSTANTS-

AEG M15A

NO.	MSD	LSD	NO.	MSD	LSD	NO.	MSD	LSD	NO.	MSD	LSD
00	0#	0 -	10	0-	15	36	0#	0#			
01	6a	6#	27	0#	0#	37	2 9	1#			
02	4 5	6 9	28	0#	0#	38	0#	0#			11
03	2a	3a	29	0#	0#	39	1#	0#			
04	0#	8a	30	0#	0#	40	0#	0#			
05	4#	25	31	4a	0a	41	2 9	9 🖠			
06	15	3#	32	0#	0#	42	0#	0#			
07	0#	0#	33	0#	0#	43	0#	0#			
08	0#	2#	34	2 9	9 \$	44	0#	0#			
09	0#	0#	35	6#	6∮	45	0#	0#			

- a INDICATES CONSTANT VALUE IS MANDATORY FOR THIS MODEL TRANSPORT.
- INDICATES CONSTANT VALUE MAY REQUIRE TRIMMING TO ACHIEVE OPTIMUM PERFORMANCE.
- # INDICATES CONSTANT VALUE MAY BE CHANGED TO SELECT VALUES AND INVOKE ROUTINES APPROPRIATE TO SPECIFIC OPERATIONS AT OPTION OF USER.
- INDICATES VALUE DOES NOT INFLUENCE OPERATION OF THIS RECORDER.
 NOTE: THESE CONSTANT VALUES APPLY TO SOFTWARE PROGRAMS J.2 AND HIGHER.